



## **APPLICATION PREPARATION**

- Clean and dry the crack or damaged area. Use a grinder, crack chaser, or chisel to open cracks to a minimum 1/8" width and depth.
- Remove dust, debris, oil, and moisture using a vacuum and wire brush.

## **MIXING INSTRUCTIONS**

RepairX 10 has (2) components; Part A and Part B. To mix, pour Part B into Part A and blend for 15 seconds. Do not mix more product than can be placed in the space of three (3) minutes. If pigment is required, add 1 oz. per every 10 oz. of mixed (A+B) material. Stir the pigmented mixture thoroughly until the color is homogenous.

## **APPLICATION INSTRUCTIONS**

- Inject or pour the mixed polyurea into the crack, joint, or repair area.
- Overfill slightly, as the material may shrink minimally during cure.
- For spalls, pour and trowel flush with the surface quickly before set time.
- Once cured (typically within 5-15 minutes), grind flush with the concrete using a floor grinder or cup wheel.