



APPLICATION PREPARATION

- Clean and dry the crack or damaged area. Use grinder, crack chaser, or chisel to open cracks to a minimum 1/8" width and depth.
- Remove dust, debris, oil, and moisture using a vacuum and wire brush.

MIXING INSTRUCTIONS

Thoroughly shake the cartridge for several minutes before using material. If you mix RepairX by hand pour part B into part A and blend for 8-10 seconds.

Do not mix more product than can be put down in the space of three minutes. If adding pigment to kits, use 1 oz. of pigment to 10 oz. of A & B mixture. Stir combined mixture thoroughly for 8-10 seconds to make color homogenous and eliminate streaking.

APPLICATION INSTRUCTIONS

- Inject or pour the mixed polyurea into the crack, joint, or repair area.
- Overfill slightly, as the material may shrink minimally during cure.
- For spalls, pour and trowel flush with the surface quickly before set time.
- Once cured (typically within 5-15 minutes), grind flush with the concrete using a floor grinder or cup wheel.